

# PRESTO TESTING™ INSTRUMENTS

## PACKAGE LEAK DETECTOR & SEAL INTEGRITY TESTER

Leak Detector & Seal  
Tester for Packaging of:

Frozen Foods  
Face Wipes  
Cheese & Dairy  
Pet Food  
Medical & Pharmaceutical  
Cereal & Grains  
Bakery Products  
Snack Food  
Coffee  
Confectionery  
Automotive  
Industrial  
Much, much, more



**VACUUM**  
**Leak Detector**  
Model PRIMA - DRY & WET



**VACUUM**  
**Leak Detector**  
Model PRIMA - DRY



Model DIGITAL - ECO



Model DIGITAL- PET  
BOTTLES

*Invent The  
Future With Us*

DELIVER PRODUCTS WITH  
**SPEED & EFFICIENCY**



- **Presto™** vacuum leak detectors are utilized to test seal integrity and substrate strength including: stand-up pouches and packets of various varieties, solid trays, pouches that are gas flushed (MAP), automotive, industrial, medical and all types of packaging.
- The **Presto™** leak detector comprises of a transparent vacuum tank, a vacuum system, a control valve and a vacuum gauge to indicate desired level of vacuum. The unit is mounted on a stainless steel body.
- The equipment is simple, trustable and repeatable allowing consistent quality control and process monitoring.
- The package to be tested is submersed or placed in the tank and the lid is closed. The valve is then engaged, at which time, if there is a leak, the operator can easily see air leaking or gas in the form of bubbles escaping from the package. A complete test can be done in less than 30 seconds!
- Visually analyzing where the seal is faulty allows precise adjusting of machine seal bar parameters such as dwell, temperature and pressure.
- There are electric vacuum generation; the vacuum is created using electric vacuum pump.
- **PRESTO™** vacuum leak can be used for measuring a minimum pass test as well as a product fail point test. In addition, the device can be used for altitude simulation testing.



**ADJUST VACUUM LEVEL  
TO EVALUATE SEAL  
INTEGRITY**



**Faulty Seal -  
See the Air  
Bubbles!**



**Good Seal Integrity -  
No Bubbles!**

**Pick the model to suit  
your package size!**

Table Top		
MODEL #	INSIDE TANK DIMENSIONS	MAX. PACKAGE SIZE
<b>PVL - 0130 (150 mm)</b>	13.5x15x16 inch 340x380x407 mm	3.5x6x6.6 inch 90x150x170 mm
<b>PVL - 0130 (300 mm)</b>	13.5x15x16 inch 340x380x407 mm	13.5x15x16 inch 180x300x355 mm
<b>PVL-0130-PB</b>	13.5x15x16 inch 360x380x734 mm	5.9x11.8x13.5 inch 150x300x340 mm
<b>PVL-0132 (PRIMA-DRY)</b>	14x15x27 inch 360x380x690 mm	13.5x15x16 inch 180x300x355 mm
<b>PVL-0132 (PRIMA-DRY)</b>	14x15x27 inch 360x380x690 mm	3.5x6x6.5 inch 90x150x170 mm
<b>PVL-0131 (PRIMA - WET&amp;DRY)</b>	18.3x21x20 inch 465x534x513 mm	11x13.3x19 inch 280x340x484 mm

**PRESTO TESTING™  
INSTRUMENTS**

Presto Stantest Private Limited

I-42, DLF Industrial Area Phase-I, Delhi Mathura Road, Faridabad 121003, Haryana, India